





SINGER* 20





THE SINGER MANUFACTURING COMPANY





SINGER 20^{*}





Sewing Machine











SEWHANDY^{*}


























































Form K6273
(957)

*A Trade Mark of THE SINGER MANUFACTURING COMPANY

Printed in Great Britain

